



"Telecommunication Products to solve Telecommunication Problems"


# CK-1A6 Promotion-On-Hold Module

**For the AT&T phone models:  
SB67118, SB67138, SB67158**

3/7/14 (3D PAD)

## Introduction

Thank you for purchasing the Skutch CK-1A6 Promotion-On-Hold Module for the AT&T SB67118, 138, 158 four line cordless phone systems. This unit **ONLY** works with these phone models. The CK-1A6 is a true plug and play device. This unit requires an external sound source such as a MP3 Player or CD Player to provide the Promotion-On-Hold audio. When a call is placed ON HOLD or TRANSFERRED to another phone, from the base or any cordless phone, the ON HOLD caller will hear the Promotion-On-Hold audio. When the line is re-answered, the audio automatically stops. It's that simple!




## Installation

- 1- Position the CK-1A6 box under the base telephone with the jacks facing towards the back of the phone. (See Fig. 3).
- 2- The SENSOR Board **MUST** be stuck to the phone or this unit will not function.
- 3- Make sure that the surface on the telephone is clean and free of dust and/or oil.
- 4- Peel the paper protectors off back side of the "SENSOR BOARD" and attach it to the phone as shown in Fig. 2. Note that the SENSOR Board **MUST** cover the Line buttons on the phone and must fit flush against the phone. The Sensor Board has been designed to

fit the contour of the phone, so no alignment is needed. Press down firmly to adhere to phone.





4- Connect the short modular cord from [1&2 to Phone] on the CK-1 to the [L1/L2] jack on the Phone.

5- Connect the short modular cord from [3&4 to Phone] on the CK-1 to [L3/L4] jack on the Phone.

6- The audio cord that comes with the CK-1A6 is ONLY used for CD Players. If you have a digital player, then you should be using the audio cord that came with your digital unit. Connect the proper audio cord from your music source, to the AUDIO IN jack on the back of the CK-1 box.

7- Connect a MOD cord from Telephone Wall Jack 1&2 to [1&2 to Line] on CK-1.

8- Connect a MOD cord from Telephone Wall Jack 3&4 to [3&4 to Line] on CK-1.

9- Connect the POWER CUBE from the CK-1 box to 115VAC power.

## Disabling Internal Music On Hold SB67118

1- Press "MENU/ENTER" button.

2- Press down arrow repeatedly until arrow points at "Base Setup", then Press "MENU/ENTER"

3- Press down arrow repeatedly until arrow points at "Music On Hold", then Press MENU/ENTER.

4- Press "MENU/ENTER" then press DOWN ARROW. Display should read "Off"

5- Press "MENU/ENTER" then "EXIT".

## **Testing the System:**

1- Pickup line 1 on your telephone. The line one Green LED on the SENSOR BOARD should light up.

2- Repeat this test for lines 2-4. If all lines light up when picked up, the CK-1 is working properly. If the lights on the SENSOR BOARD do not light up, then

- a) Make sure that the CK-1 and Phone is connected to power.
- b) Make sure that the SENSOR BOARD is aligned properly. (Fig 2)

## **I hear Music when I pick up the phone**

It is normal to hear a burst of music when a call is picked up from a HOLD condition. The maximum length of the burst should be under 1 second. This is normal and is due to the communication structure of this family of phones.

## **Lights on CK-1 Box.**

When you place a line on HOLD, the corresponding LED on the rear of the CK-1A6 box lights up to confirm the Promotion-On-Hold condition.

## **Using Other Phones with the AT&T SB67118 phone**

This AT&T phone system can be used with other makes and models of phones, but when the other phones are placed ON HOLD, the caller will not hear Music On Hold.

## **Tech Support - 916-786-6186**

If you have any problems getting the unit to work properly feel free to give us a call. Technical Support is available between the hours of 7:30 AM and 4:30 PM Pacific Time, Monday through Friday.

## **• ONE YEAR LIMITED WARRANTY**

This SKUTCH PRODUCT is warranted against defects for a period of one (1) year from the date of the original invoice. Within this period, we will repair it without charge for parts and labor. To obtain warranty service the product must be returned, at the customer's expense, to SKUTCH Electronics along with a copy of the original invoice. After the unit has been repaired, SKUTCH will ship the PRODUCT back via UPS GROUND service at our expense. If any other form of return shipment is requested, the customer will pay for 100% of the shipping cost.

This Warranty does not apply if in the sole opinion of SKUTCH Electronics, the PRODUCT has been damaged by lightning or any other Acts of God, or by accident, misuse, neglect, or improper packing, shipping, modification or servicing by other than an authorized SKUTCH Service Center.

EXCEPT AS SPECIFICALLY PROVIDED IN THIS AGREEMENT, THERE ARE NO OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OR MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE AND IN NO EVENT SHALL SKUTCH ELECTRONICS BE LIABLE FOR LOSS OF PROFITS OR BENEFITS, INDIRECT, SPECIAL, CONSEQUENTIAL OR OTHER SIMILAR DAMAGES ARISING OUT OF ANY BREACH OF THIS WARRANTY OR OTHERWISE.